



- **Direct drive – backlash free**
- **Micro-radian resolution**
- **No power draw in hold position**
- **Quick response**

The LR80 motor is intended for a large range of applications. Very high speed dynamics and micro-radian precision makes it ideal for numerous applications. High torque output in a small package is also beneficial.

The Piezo LEGS technology is characterized by its outstanding precision. Fast speed and quick response time, as well as long service life are other benefits. In combination with the micro radian resolution the technology is quite unique.

The motor is ideally suited for move and hold applications or for automatic adjustments. When in hold position it does not consume any power. The drive technology is direct, meaning no gears are needed to create motion. The motor has no mechanical play or backlash. The LR80 motor is available in standard version, and vacuum version.

Operating modes

The motor can move in full steps (waveform-steps), or partial steps (micro-steps) giving positioning resolution in the micro-radian range. Speed is adjustable from micro-steps per second up to max specified.

Controlling the motor

PiezoMotor offers a range of drivers and controllers. The most basic one is a hand-held push button driver. Another option is an analogue driver that regulates the motor speed by means of an ± 10 V analogue interface. More advanced alternatives are micro-step drivers/controllers in the 100- and 200-series. These products allow for closed loop control and precise positioning. The micro-stepping feature divides the wfm-step into thousands of small increments which results in micro-steps in the micro-radian range. The PMD units are straight forward to use, supports quadrature and serial sensors, and have multiple I/O ports.



PMD101



PMD206

Design your own driver

Some customers prefer to design their own driver for ease of integration. PiezoMotor provides information to assist in the design.

Ordering information

Motors

LR8012A-00A00	Standard version, stainless steel
LR8012B-00B10	Vacuum version, stainless steel

Drivers and Controllers

PMCM21	Hand-held push button driver
PMD101	1-axis micro-stepping driver
PMD206	6-axis micro-stepping driver
DMC-30019	Controller

Operating Principle

The Piezo LEGS walking principle is of the non-resonant type, i.e. the position of the drive legs is known at any given moment. This assures very good control of the motion over the whole speed range.

The performance of a Piezo LEGS motor is different from that of a DC or stepper motor in several aspects. A Piezo LEGS motor is friction based, meaning the motion is transferred through contact friction between the drive leg and the drive disc. You cannot rely on each step being equal to the next. This is especially true if the motor is operated under varying torques, as shown in the diagram below. For each waveform cycle the Piezo LEGS motor will take one full step, referred to as one *wfm-step* (~0.9 mrad at no load with waveform *Rhomb*). In the schematic illustrations to the right, you can see one step being completed. The rotational velocity of the drive axle is the *wfm-step* angle multiplied with the waveform frequency ($0.9 \text{ mrad} \times 2 \text{ kHz} = 1.8 \text{ rad/s} = 100 \text{ }^\circ/\text{s}$).


Micro-stepping is achieved by dividing the *wfm-step* into discrete points. The resolution will be a combination of the number of points in the waveform, and the torque. Example: at 40 mNm torque the typical *wfm-step* angle with waveform *Delta* is ~0.45 mrad, and with 8192 discrete points in the waveform the micro-step resolution will be ~50 nrad (nano-radians).




1 When all legs are electrically activated they are elongated and bending. As we shall see below, alternate legs move as pairs. Arrows show the direction of motion of the tip of each leg.



2 The first pair of legs maintains contact with the drive disc and moves towards the right. The second pair retracts and their tips begin to move left.



3 The second pair of legs has now extended and repositioned in contact with the drive disc. Their tips begin moving right. The first pair retracts and their tips begin to move left.



4 The second pair of legs has moved right. The first pair begins to elongate and move up towards the drive disc.




Figure 1 Motor performance with waveform *Rhomb* (filled) and waveform *Delta* (dotted). *Wfm-step* angle is the average distance the drive disc rotates when the legs take one *wfm-step* (i.e. for one waveform cycle). Note: Standard deviation σ of 0.1 mrad should be taken into account. Typical values are given for 20°C.

Technical Specification

Type	LR8012A standard	LR8012B vacuum	Unit	Note
Angular Range	360	360	°	continuous
Speed Range ^a	0-100	0-100	°/s	recommended, no load
Step Angle ^b	450	450	μrad	one wfm-step
	0.05 ^c	0.05 ^c	μrad	one micro-step ^c
Resolution	< 0.1	< 0.1	μrad	driver dependent
Recommended Operating Range	0-40	0-40	mNm	for best micro-stepping performance and life time
Stall Torque	80	80	mNm	
Holding Torque	90	90	mNm	
Shaft Load, Max.	3	3	N	radial (5 mm from mounting face)
	2	2	N	axial
Shaft Press Fit Force, Max.	5	5	N	
Vacuum	-	10 ⁻⁷	torr	
Maximum Voltage	48	48	V	
Power Consumption ^d	7	7	mW/Hz	=0.7 W at 100 Hz wfm-step frequency
Connector	JST BM05B-SRSS-TB	soldered cable with JST 05SR-3S		
Mechanical Size	Ø23 x 34.1	Ø23 x 34.1	mm	see drawing for details
Material in Motor Housing	Stainless Steel	Stainless Steel		
Weight	60	60	gram	
Operating Temp.	-20 to +70	-20 to +70	°C	

a. Max value is typical for waveform *Rhomb* at 2 kHz, no load, temperature 20°C.

b. Typical value for waveform *Delta*, 40 mNm torque, temperature 20°C.

c. Driver dependent; 8192 micro-steps per wfm-step for driver in the PMD200-series.

d. At temperature 20°C, intermittent runs.

Note: All specifications are subject to change without notice.

Item no.

LR8012 -

Family name

LEGS Rotary

Stall torque

80 = 80 mNm

Version**Motor type**

A = SS / Stainless Steel

B = SSV / Stainless Steel Vacuum

Encoder

00 = No Encoder

01 = Magnetic 13 bit encoder

Connector/Cable**Motor type A**

A00 = JST connector, no cable

A05 = Same as K05

A15 = Same as K15

K05 = 0.5 m cable for driver PMD101 and PMCM31

K15 = 1.5 m cable for driver PMD101 and PMCM31

L05 = 0.5 m cable-kit for driver PMD206 and PMD236

L15 = 1.5 m cable-kit for driver PMD206 and PMD236

Motor type B

B10 = 1.0 m Teflon flying wires PTFE AWG28 for connection to driver PMD101 and PMCM31

For connection to driver PMD206 or PMD236 you need a D-sub adapter, p/n CK6280.

Note: All combinations are **not** possible!

Visit our website for application examples,
CAD files, videos and more...

www.piezomotor.com



PiezoMotor Uppsala AB
Stålgatan 14
SE-754 50 Uppsala, Sweden

Telephone: +46 18 489 5000
Fax: +46 18 489 5001

info@piezomotor.com
www.piezomotor.com

